


Quick Start Guide

MODEL: RS-BM500



INTRODUCTION




No.	Description
1	Battery Remaining Capacity
2	Charge/Discharge Indicator
3	Percentage of Battery Remaining
4	Back Button
5	Up Button
6	Down Button
7	OK Button
8	Battery Watts Input/Output
9	Remaining Time
10	Battery Amps Input/Output
11	Battery Voltage

SPECIFICATIONS

Battery Voltage Range	8-120V
Working Current Consumption	10mA
Standby Current Consumption	1mA
Capacity Accuracy	±1.0%
Voltage Accuracy	±1.0%
Current Accuracy	±1.0%
Backlight Operating Current	80mA
Capacity Setting Range	0.1-9999Ah
Current Range	0-500A
Temperature Range	14-140°F

METAL BEZEL DRAWING



Model: RS-BM500BZ