

EN



In addition to what is explained in this guide, the safety and installation information provided in the technical manual must be read and followed. The technical documentation and the interface and management software for the product are available at the website.

Power and productivity
for a better world™ **ABB**

1. Description of the plant with MICRO inverter

The plant is composed of a group of MICRO inverters that convert direct electric current from a photovoltaic module into alternating electric current and feeds it to the electrical grid.

The diagram shows several MICRO inverters communicating with a CDD, which in turn connects, by Ethernet or Wireless, to a PC or a router connected to internet.


It is possible to manage and monitor the plant using a PC or Smartphone with internet access by registering on the Aurora Vision Plant Viewer.

The CDD device must be configured in order to commission the photovoltaic system. The following configurations must be completed on the CDD for proper operation of the system:

- Acquisition of MICRO inverters
- Setting geographical parameters
- Setting of grid standard for the country/region of installation.

These operations can be carried out using the display (step 7 of this guide) or the Web Server integrated in the CDD. When configuring using the Web Server it is necessary to connect the CDD to a PC via Ethernet or Wireless (step 5 of this guide).

Once the configuration has been completed, using an internet connection the device can be registered on the Plant Viewer web portal, which allows remote monitoring of the MICRO inverters making up the photovoltaic system (step 10 of this guide)



2. Components and overall dimensions

- 01 Wireless antenna
- 02 Status LED
- 03 Radio antenna (MICRO inverter)
- 04 Display
- 05 Button pad
- 06 Ethernet port
- 07 Power Supply connector
- 08 Ethernet communication status LED

The UP and DOWN buttons are used to: Move around a menu or to Increase/decrease settable values. Choose settings.

The ESC button returns to the previous menu.

The ENTER button accesses the desired submenu or confirms a settable value/parameter.

Press the UP and DOWN buttons simultaneously to access the main menus for STATISTICS, VIEW INFORMATION and CHANGE SETTINGS.

Pressing any button during the normal operation (when GENERAL INFORMATION is displayed) you gain access to the set up basic, and information screens related to the CDD.

3. Preplan the installation

- Before INSTALLING MICRO/CDD system consider the following Assumptions:
1. Evaluate possible obstacles that can restrict or nullify the radio communication among MICROS and CDD; it must be analyzed the communication quality and the right position (as shown in the step 4) considering the possibility of having to extend the radio antenna externally (CDD Antenna Extension Cable).
 2. Each CDD has a capacity to monitor up to 30 MICRO inverters. For more than 30 MICRO inverters, it is mandatory to install more than one CDD.
 3. For Wireless (WLess) connection with customer's Router, make sure that the router is available on the Compatibility list (www.abb.com/solarinverters), otherwise use the Ethernet communication, so there must be an unused Ethernet port on the customer's Router.
 4. For installations with multiple CDDs, it is recommended to acquire all MICRO inverters before mounting them on the roof, using the "MICRO pre-installation kit" and related guidelines.

4. Environment and obstacles evaluation

Where to place the CDD and when to extend outside radio antenna

The communication among MICRO inverters and CDD is based on radio signal that could be limited by obstacles and distance. The radio signal level between CDD and MICRO inverter can be increased in different ways:

1. Change the direction of the antenna. The antenna has deadzone at its end. It should not be facing the MICRO inverters as shown in the picture.

2. Find a new location for the CDD taking care about the signal decrease due to materials through which the radio signal has to pass:

Material	Relative signal range reduction
Open Field	Approximately 50 meters
Wood / Glass	From 0 to 10%
Stone / Pressed cardboard	From 10 to 40%
Reinforced concrete	From 60 to 90%
Metal	Up to 100 %

The RF signal quality is displayed using the CDD (GENERAL INFORMATION. See step 9).

3. Install an extension cable for the antenna (CDD Antenna Extension Cable). The cable allows the antenna to be installed at a distance over the obstacle for the radio signal.

Install the antenna in an outdoor rated plastic box, 15cm / 6in above roof, and in line-of-sight of panels.

It could be used the already existing conduits of residential electrical system or of the TV antenna to bring the CDD's Antenna outside.

5. Environment and obstacles evaluation

5. Metal or reinforced concrete. Install the antenna in plastic box, 15cm/6in above roof, and in line-of-sight of panels.

7. Windows. Distance less than 30m/100ft.

5. Connection and configuration of the CDD to the Router / PC

Wireless connection

The wireless connection of the CDD is enabled by default and requires a router with IEEE 802.11b communication protocol that will transmit the data to the web portal when there is an internet connection. Requirements of the router:

- Compatibility with IEEE 802.11 communication protocol
- If router is not on the compatibility list on the website, a standard access point may be utilized to bridge the CDD to the incompatible router.
- Visible SSID
- WPA and WPA-2 security protocols supported.

This type of connection can be used both during configuration of the system to access the CDD internal configuration pages (local web server) and for data transmission to the web portal in order to monitor the system.

- When the CDD is first started up, a search is performed to find available wireless networks.

- The display shows the number of networks detected (XX).

- Press ENTER to access the selection menu for the IEEE 802.11 network

The first line shows: network number (XX), type of protection (Open, WPA/WPA2) and level of the signal (variable from 1 to 4 and indicated with the characters "□"). The second line shows the network name (SSID).

The continuation of the installation differs depending on the type of protection of the selected network (Open, WPA/WPA2).

1. Configuration with open networks (Open)

If there is a MAC Address filter active on the router, add the CDD device to the list of enabled MAC Addresses.

```

PIN: P1111111111
SN: Y1111111111
MAC WF1: A1B1C1D1E1F1
MAC RF: A2B2C2D2E2F2G2H2
MAC ETH: A3B3C3D3E3F3
            
```

 - Press ENTER to select the wireless network and confirm start-up of the connection.
 - The CDD starts the connection to the Wireless network and within a few seconds the display shows a message indicating the result of the connection attempt
 - At the end of the procedure the message "WLess Enabled" will appear.
2. Configuration with protected WPA/WPA2 networks

If there is a MAC Address filter active on the router, add the CDD device to the list of enabled MAC Addresses.

 - Before starting the connection attempt, the CDD requires the inputting of the protection key of the Wireless network. In order to input the access key, press the UP or DOWN buttons to scroll through the list of characters and ENTER to select (in the event of an error, press ESC)
 - Once the inputting is finished, press ENTER twice to start the connection attempt
 - The CDD starts the connection to the Wireless network and within a few seconds the display shows a message indicating the result of the connection attempt
 - At the end of the procedure the message "WLess Enabled" will appear

Autoconnection configuration

The CDD automatically memorizes the parameters of the last connection made (SSID and network key). If the automatic reconnection function is enabled, and in the event of any disconnection, the CDD will automatically reconnect to the set Wireless network.


- To enable/disable the automatic connection function, access "GENERAL INFORMATION" (see the menu structure in this guide), use the UP and DOWN buttons to scroll to the item "Autoconnection" and then press ENTER.
- Press UP and DOWN to activate or deactivate the function.
- Press ENTER to confirm the selection.

Hard-wired Connection (Ethernet)

- Disable the Wireless connection (enabled by default) before connecting the Ethernet cable.
- To enable/disable the wireless connection, access "GENERAL INFORMATION" (see the menu structure in this guide), use the UP and DOWN buttons to scroll to the item "Wless enabled" and then press ENTER.
- Select No and then ENTER. The Wless is disabled.
- Press the UP and DOWN buttons simultaneously for 3 seconds, then enter the password (0010) to access to advanced menus.
- Select CHANGE SETTINGS > NETWORK > SELECT NETWORK > ETHERNET > PRESS ENTER
- The CDD will restart automatically

The CDD may be hardwired to the computer in either of two ways:


- 1. Direct to the computer using a Ethernet cable**
This type of connection must only be used during configuration of the system to access the CDD internal configuration pages (local web server)
- 2. Through a router using a Ethernet cable**
This type of connection can be used both during configuration of the system to access the CDD internal configuration pages (local web server) and for data transmission to the web portal in order to monitor the system.




With both methods be careful not to put the Ethernet cable in the RJ45 connector for RS-485 serial communication.

If the computer is directly connected to the CDD without any router, and if the computer is set for an automatic IP address, it is necessary to follow the procedure below:

- Click on the internet icon and open the Network and Sharing Center
- Click Local Area Connection (LAN)
- Click Properties
- Click Internet Protocol Version 4 (TCP/IPv4)
- Click Get the following IP address and type a different IP address from that of the CDD (e.g. if the CDD IP gateway address is 192.168.0.100, type 192.168.0.101) and click OK
- The IP address of the CDD is shown on the display by pressing any button.



Once these parameters are set, input the IP address of the Web Portal (CDD) in the address bar of the Internet Browser and proceed with the commissioning of the plant.



The Firmware upgrade can be made in two different ways:


- a. CDD Firmware update via Aurora Vision® following the procedure on step 10. Once the registering phase will be completed the upgrade process will be performed automatically**
- b. CDD Firmware upgrade via "CDD web user interface" (both with Ethernet and WLess connection).**
Hardware and software necessary to perform the upgrade:
Personal computer; Ethernet cable or Wireless router; CDD to be updated ; CDD Firmwares (Ethernet and Wireless)

The CDD Firmwares are available on the web site <https://registration.ABBSolarinverters.com>. Download the firmwares, save them on your PC and then follow the below procedure:

- Launch the browser internet (ex. Mozilla)
- Enter the IP address of the CDD in the address bar (viewable on the display)
- Once the home page has appeared, click on "upgrade" -> "CDD local Upgr."
- Access to the menu by entering the USER ID "admin" and PASSWORD "admin"
- Click "browse" and choose the firmware x.x.x Eth .ben (where x.x.x refers to the firmware version) and click "open"
- Click "upload"
- Wait for the message "File correctly uploaded!"
- Now the ethernet firmware installed is the x.x.x Eth
- Click "browse" and choose the firmware x.x.x Wlan .ben and click "open"
- Click "upload"
- Wait for the message "File correctly uploaded! Ethernet Firmware loaded: x.x.x, WLess Firmware loaded: x.x.x"
- Click on "Click here to reboot the CDD and make the update effective"
- Check on the display that the CDD reboots
- Wait for the reboot (30 seconds) and click "home"
- Now the CDD firmware is updated to the last available release
- Check on the display of the CDD that the release installed is the one uploaded (menu "view information" -> "firmware rel.")


As well as being used for acquisition of the MICRO inverters by the CDD, the local Web Portal makes it possible to monitor the whole system constantly, showing the data for each individual inverter. The various menus allow you to:

- "Home" Menu**
 - The HOME page displays all the MICRO inverters with their serial numbers, instant energy output and radio signal level. The table on the left shows the data for the whole system (energy output, total energy, CO2 savings and system status).
- "View" Menu**
 - Plant Info > plant data (name of the plant, place, country standard, etc...)
 - RF Signals > a graph is displayed showing the radio signal strength for each inverter, and the messages sent.
- "Config" Menu**
 - Plant > setting of plant information (Name, place, etc) and grid standard of MICRO inverter
 - Network > set the parameters for the network (DHCP) and the "Plant Viewer" web portal (Sending data and events to the portal, automatic updates, etc.). If automatic updates are monitored, the customer will receive an e-mail notifying that a new version of the firmware is available.
 - Micro Manager > Used to acquire/remove the MICRO inverters in the system from the "CDD embedded web user interface"
 - Date/Time > sets the CDD date and time
 - CDD Clone > used to clone the CDD if it has to be replaced. This function allows the new CDD to be associated with the MICRO inverters already installed in the system
 - CS Param-> Used to modify the editable parameters in the Country Standard
 - Ground Fault/Energy > Used to unlock the inverter that triggered a Ground Fault error and to reset the energy value for each MICRO inverter
 - Change Pass > Used to change the password giving access to the Local Web Portal advanced functions (by default Username: Admin / Password: Admin)
- "Events" Menu**
 - Accesses the list of events signaled by the MICRO inverters or by the CDD.
- "Upgrade" Menu**
 - CDD Remote Upgr. > Finds the latest Firmware version for the CDD
 - CDD Local Upgr. > Used for local update of the CDD, loading the files directly from the PC
 - CS Local Upgr.> Used to load the list of Country Standards locally
- "Registration" Menu**
 - Accesses to the Self Registration procedure in the Aurora Vision Plant Viewer web Portal (it is necessary to be connected to internet).
- "?" Menu (Help)**
 - Contacts for the Service in case assistance is needed.



The display (consisting of 2 lines with 16 characters per line) can be used to navigate the menu using the buttons UP, DOWN, ESC and ENTER and enables you to:


- View the operating status of the inverter and the statistical data
- View service messages for the operator
- View alarm and fault messages
- Change the inverter settings



In order to improve the acquisition process and as a consequence the communication among MICROs and CDD is strongly recommended to pre-acquire all MICROs before mounting them on the roof using the "MICRO Pre-installation Kit" and related guideline (visit the website or contact tech support to obtain information about this).


The acquisition process can be performed directly by display or using "CDD embedded web user interface" :

- 1. Acquisition of the MICRO inverters via the display**
The MICRO inverters can be acquired directly via the CDD display.
Press the UP and DOWN buttons simultaneously from the cyclic CDD screens, and enter the advanced level password (0010) to access the menus.
Use the UP and DOWN keys to navigate to the CHANGE SETTINGS menu, press ENTER and scroll through the menu to MICRO MANAGER.
Before starting acquisition of the MICRO inverters a screen will be displayed in which the system co-ordinates and time zone must be set. If this step is not carried out it will not be possible to carry out any other operation. Use the UP and DOWN keys to set the latitude and longitude of the system and press ENTER to confirm.
Then press ENTER to access the setting SET TIME ZONE, use the UP and DOWN keys to select the required time zone and press ENTER to confirm.
It is now possible to proceed with acquisition of the MICRO inverters.



- 2. Acquisition of the MICRO inverters via the integrated web server**
On completing the installation phase, the CDD will be connected to the PC.
Commissioning the system involves acquisition of the MICRO inverters by the CDD:

- Enter the IP address of the Web Portal in the URL address bar of your browser, and wait until the local web portal is displayed.
Before starting acquisition of the MICRO inverters it is compulsory to set the system's latitude, longitude and time zone parameters, otherwise it will not be possible to carry out any other operation
A browser with active Javascript must be used to view the Local Web Portal pages properly.



- In the drop-down menu select the item Config>MICRO manager. This submenu requires authentication
Username: admin
Password: admin
- Click on the icon START ACQUISITION to start scanning.
There is no timeout for the acquisition procedure. It must be terminated by the user by clicking on "STOP ACQUISITION" once all MICRO serial numbers have been acquired.
- Check that all the MICRO inverters present in the system have been acquired. The MICRO inverters can be identified using the radio communication MAC address (MAC RF) indicated on the cover, on the carrier box or on the removable adhesive labels used to draw up the system map.
MICRO inverters with a Signal less than 40 should not be assigned, as they would be too weak. In this case it is necessary to assess whether to install the CDD in a new position.
- Select the MICRO inverters to be associated with the CDD and press CONFIRM
- The next step is to define the grid standard for the country of installation (Country Standard). The CDD will set the standard selected on each of the MICRO inverters in communication with it.
- Do not set grid standards that do not match those of the country of installation!
- The last step relates to registration of the CDD on the Plant Viewer web portal.
Click on the link "CLICK HERE FOR REGISTER YOU CDD" to register the CDD on the Plant Viewer web portal
- To complete the acquisition process without registering the CDD on the Plant Viewer web portal (or to register later), click on PLEASE CLICK HERE TO COMPLETE
- Click HOME to go back to the main screen.

At this point the CDD can be installed on the wall, as all the configuration procedures have been completed successfully.


Once the acquisition of the MICRO inverters is completed it is possible to configure the remote monitoring of the plant on the Plant Viewer web portal using the Self Registration procedure.

- To start the self-registration process go to <https://register.auroravision.net/cdd?mac=AA:BB:CC:DD:EE:FF:GG:II> (the page will be automatically opened if at the end of the acquisition process for the MICRO inverter you go to "CLICK HERE TO REGISTER YOUR CDD XX:XX:XX:XX:XX:XX:XX:XX")
The registration process is completed in three steps:
1. Enter your personal contact information and validate your email account.
You will be sent an email with a link to validate your email address. Open the e-mail and click on the link to continue the registration.
If you do not validate the account within 3 days the account will be invalidated and you will have to start over.
2. Provide details about your solar power site/home.
It is important to provide the installer's name and contact information to help direct current and future homeowners to the installer for any future project and service needs.
Your site information defaults to the homeowner's address but can be updated to a different address for alternate locations such as the homeowner's second home.
3. Link and validate your CDD to the solar power site.
Make sure the CDD is connected to the internet.
Enter the CDD's RF MAC address (MAC RF) in the 8 display fields
Click on the Validate button
If the CDD is validated, the logger and all configured MICRO inverters will be displayed
Click I'm Done to complete the registration process you will receive an e-mail confirming that the registration has been successfully completed.

The free Aurora Vision Plant Viewer offers monitoring of the plant remotely (via internet).

The portal is divided 3 main sections:
The upper section has general information about the system
In the middle is the graph of total production of energy for a period which can be set (from a single day up to 365) and the output power of each MICRO inverter
On the bottom are the Environmental Benefits based on the total energy produced by the plant.

In addition to the monitoring, the portal offers automatic upgrade of the firmware installed in the MICRO inverters and the CDD device. Every time new firmware is available, an e-mail asking for confirmation to do the upgrade will be sent to the plant owner.



CDD	
Communication To Inverter	
Type	Radio IEEE 802.15.4
Max Distance (free space)	50 m
Max number of devices	30
Communication To Router/PC	
Wireless Communication	Communication protocol IEEE 802.11b, 2.4 GHz , 1 - 11 Mbit/s
Wired Communication	Ethernet RJ45 10/100 Mbps
Features	
Operation	CDD embedded web user interface
Monitoring System	Wireless and Web-Based Monitoring through CDD
Power Supply	
Adapter Input	100...240 Vac ; 50/60 Hz
Adapter Output	5 Vdc - 1 A
Power Consumption	typical 2.5W/ max. 5W
Environmental	
IP Degree	IP20 / NEMA 1
Ambient Temperature	-20...+55 °C / -4...131°F
Relative Humidity	<90% non condensing
Physical	
Dimension (H x W x D)	150x180x25 mm / 5.9x7x1" (not extended antenna)
Weight	0.6 kg / 1.32 lbs
Mounting System	Wall mounting (screws provided)
Accessories	
Antenna extension cable	Optional
Note: Features not specifically mentioned in this data sheet are not included in the product	

Contact us
www.abb.com/solarinverters
CDD-Quick Installation Guide EN-Rev D
EFFECTIVE 2014-03-27
© Copyright 2014 ABB. All Rights Reserved.
Specifications subject to change without notice.

