








SCCP05-050

PWM Charge Controller/Load Manager

Owner's Manual

NOTE:


- Follow instructions in order.
- Charge batteries at least once a week.
- Use reducers to connect larger wires to terminals.



SCCP05-050 Owner's Manual


5

Load & Battery Type Selection




Jumper	1	2
Present	Normal	VRLA Battery
Removed	Night Light/Dusk to Dawn	Flooded Battery

Jumper inserted at factory at both 1 and 2.



6

Data Communication / Smart Charger




*Refer manufacturer recommendations.


LED

Indicators


NOTE: LEDs glow only when the charge controller is awake.




RED



YELLOW



GREEN



NOTE: SoC percentages are approximate and are based on battery voltages.

Symbols



Caution: Equipment Damage



Caution: Shock Hazard



Caution: Hot Surface



When disposing, keep this product separate from household waste; recycle this product



Double or Reinforced Insulation



Refer to Operating Instructions


Features

1 LED Indicators



2 Users Selection Jumpers

3 PV Input




4 Battery Input



5 Load Output



6 Data Communications/USB Charger




CAUTION: Hazard to Equipment

Proprietary adapter is required.
Do not connect directly to USB Port.

NOTES:

3, 4, and 5: Use flat screwdriver with tip width <4 mm and blade length >50 mm



SCCP05-050 Owner's Manual

Specifications

Section	Name		12 Vdc		24 Vdc	
PV	Controller Type		PWM			
	Wattage (maximum)		60 W		120 W	
	V _{oc}		Max 50 Vdc			
	Short Circuit Current (maximum)		5 Adc			
Battery	Battery Type (jumper-selectable)		Flooded or VRLA			
	Nominal Voltage		12 or 24 Vdc; automatically detected			
	Battery Input (range)		9 to 16 Vdc		18 to 32 Vdc	
	Self-consumption		6.8 mA (sleep) and 60 mA (awake)			
	Conversion Efficiency (maximum)		99%			
Charger	Bulk and Absorption Voltages (maximum) for Battery Types		Flooded	VRLA	Flooded	VRLA
		Bulk	14.8 Vdc	14.6 Vdc	29.6 Vdc	29.2 Vdc
		Absorb	14.8 Vdc	14.4 Vdc	29.6 Vdc	28.8 Vdc
	Absorb Time		2 hours			
	Float Voltage		13.2 Vdc	13.5 Vdc	26.4 Vdc	27.0 Vdc
	Charging Current (maximum)		5 Adc			
	Temperature Compensation (range)		-25 mV / 5°C / cell			
	Equalize	NOTE: Enabled by removing battery jumper; loads turned off while equalizing. NOTE: Occurs every 60 days, or following a low battery load disconnect.				
Equalization Voltage (maximum)		15.5 Vdc	--	31.0 Vdc	--	
Equalization Time		1 hour				

NOTE: Numbers shown in the table are factory default settings.

Section	Name	12 Vdc	24 Vdc
Loads	Minimum Load Current	0.25 Adc	
	Maximum Output Current	5 Adc	
	Overload Time (Loads > 5 Adc)	5 min for Load > 100%, 0.1 sec for Load > 125%	
Internal Protections	Internal Protection	Battery Reversal, PV Reversal	
	Load Disconnect (Automatic Reset)	Low Battery, High Battery, Overload, Equalization	
	Load Disconnect (Manual Reset)	Overload (after 3 automatic resets)	
	Low Battery Load Disconnect	11.4 Vdc	22.8 Vdc
	Low Battery Load Reconnect	12.4 Vdc	24.8 Vdc
	High Battery Load Disconnect	15.0 Vdc	30.0 Vdc

Dimensions	Size	159 mm (6.3") x 68 mm (2.6") x 25 mm (1.0")	
	Weight	~0.18 kg (0.40 lbs)	
Cabling	Terminal Size(PV and battery)	6 mm²(#10 AWG)	
	Cable Size (minimum)	Battery	4 mm²(#12 AWG)
		PV	4 mm²(#12 AWG)
	NOTE: Larger cables should be used if battery cables exceed 3 m length. NOTE: Battery cables must be twisted together during installation.		
Environment	Operating Temperature	-40°C to 60°C	
	Humidity	0 to 95% RH non-condensing	
	Ingress Protection	IP20	
Battery Bank		Minimum 25 Ah at C/5 discharge rate	
Certifications		CE, EN 61000-6-1, EN 61000-6-3, IEC/EN 62109-1	
Warranty		2 years	

Troubleshooting

Problem	Possible Remedies (perform in order shown)
Battery not charging	1) Check battery connections 2) Check PV voltage and connections 3) Allow charger to cool
No LED indicators with PV power available	1) Check battery voltage at controller terminals 2) Check panel voltage at controller terminals
Red LED on	1) Disconnect PV 2) Disconnect battery 3) Disconnect load 4) Reconnect battery 5) Reconnect PV 6) Reconnect load
Red LED flashing	1) Disconnect loads 2) Charge battery
Yellow LED not on	Charge battery
Charging to wrong voltage	1) Check position of battery selection jumper
CCU restarting repeatedly	1) Check minimum load current 2) Increase load.